



ULTRA SPEC[®] SCUFF-X[™] INTERIOR SATIN FINISH 486

Features

- Proprietary scuff-resistance formula
- Superior durability
- Highly washable
- Quick dry
- Spatter resistant
- Easy application
- Excellent flow and leveling
- Qualifies for LEED[®] v4 credit

Recommended For

Ideal for high-traffic areas in commercial spaces such as school hallways, hospital waiting areas, hotels lobbies, gym locker rooms and bathrooms, retail fitting rooms, cafeterias, bathrooms and stairwells. In busy commercial spaces, the ability to touch-up high-traffic areas has been the answer to keep maintenance at a minimum.

General Description

A premium-quality one-component coating specifically engineered to deliver outstanding performance and protection for the toughest high-traffic areas in busy commercial spaces. This unique product offers superior durability, cleanability and scuff resistance properties than traditional 2-component epoxies in the market, without the odor, pre-mixing, pot life and application difficulties related to these products. It will hold up to repeated cleaning and scrubbing without causing any permanent damage to the paint. With its slight gloss, the Satin finish offers the benefits of richer look that is perfect elevator areas, stairwells and locker rooms. areas, stairwells and locker rooms

Limitations

- Do not apply when air and surface temperatures are below 50°F (10°C)

Product Information

Colors — Standard: White (01)	Technical Data \diamond Pastel Base	
— Tint Bases: Bases 1X, 2X Tint bases only with Benjamin Moore [®] Gennex [®] Waterborne colorant.	Vehicle Type	Proprietary Acrylic Copolymer
— Special Colors: Contact your Benjamin Moore representative	Pigment Type	Titanium Dioxide
Certification: VOC compliant in all regulated areas except for SCAQMD	Volume Solids	39 \pm 2%
<div style="border: 1px solid black; padding: 5px; width: fit-content;"> LEED[®] v4 (Low emitting product credit/Building product disclosure credit) YES </div>	Coverage per Gallon at Recommended Film Thickness	350 – 400 sq. ft.
	Recommended Film Thickness	– Wet 4.3 mils – Dry 1.7 mils
Technical Assistance Available through your local authorized independent Benjamin Moore [®] retailer. For the location of the retailer nearest you, call 1-800-826-2623, see www.benjaminmoore.com , or consult your local Yellow Pages.	Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure color uniformity and minimize the disposal of excess paint	
	Dry Time @ 77°F (25°C) @ 50% RH	– To Touch 1 Hour – To Recoat 2-3 Hours
	Painted surfaces can be washed after two weeks. High humidity and cool temperatures will result in longer dry, recoat and service times	
	Dries By	Coalescence
	Viscosity	97 \pm 3 KU
	Flash Point	N/A
	Gloss / Sheen	Satin (20-35 @ 60°) (48 @ 85°)
	Surface Temperature at Application	– Min. 50°F – Max. 90°F
	Thin With	See Chart
	Clean Up Thinner	Clean Water
	Weight Per Gallon	10.51 lbs
	Storage Temperature	– Min. 40°F – Max. 90°F
	Volatile Organic Compounds (VOC) 86 Grams/Liter 0.71 Lbs./Gallon	

\diamond Reported values are for Pastel Base. Contact Benjamin Moore for values of other bases or color.

Surface Preparation

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew. Remove any peeling or scaling paint and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding dust.

New plaster or masonry surfaces must be allowed to cure 30 days before applying base coat. Cured plaster should be hard, have a slight sheen and maximum PH of 10; soft, porous or powdery plaster indicates improper cure. Never sand a plaster surface; knife off any protrusions and prime plaster before and after applying patching compound. Poured or pre-cast concrete with a very smooth surface should be etched or abraded to promote adhesion, after removing all form release agents and curing compounds. Remove any powder or loose particles before priming. Wood substrates must be thoroughly dry.

Difficult Substrates: Benjamin Moore offers a variety of specialty primers for use over difficult substrates such as bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore® retailer can recommend the right problem-solving primer for your special needs.

WARNING! If you scrape, sand or remove old paint, you may release lead dust. **LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE.** Wear a NIOSH-approved respirator to control lead exposure. Carefully clean up with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead.

Primer/Finish Systems

New surfaces should be fully primed, and previously painted surfaces may be primed or spot primed as necessary. For best hiding results, tint the primer to the approximate shade of the finish coat, especially when a significant color change is desired. **Special Note:** Certain custom colors require a Deep Color Base Primer tinted to a special prescription formula to achieve the desired color. Consult your retailer.

Wood, and engineered wood products:

Primer: Ultra Spec® 500 Interior Latex Primer (N534) or Fresh Start® Multi-Purpose Latex Primer (N023)
Finish: 1 or 2 coats Ultra Spec® SCUFF-X™ Interior Satin Finish (486)

Bleeding Type Woods, (Redwood and Cedar):

Primer: Fresh Start® Multi-Purpose Oil Based Primer (N024) or 1-2 coats of Fresh Start® High-Hiding All Purpose Primer (046) may be used
Finish: 1 or 2 coats Ultra Spec® SCUFF-X™ Interior Satin Finish (486)

Drywall:

Primer: Ultra Spec® 500 Interior Latex Primer (N534)
Finish: 1 or 2 coats Ultra Spec® SCUFF-X™ Interior Satin Finish (486)

Plaster:

Primer: Fresh Start® High-Hiding All Purpose Primer (046) or Fresh Start® Multi-Purpose Latex Primer (N023)
Finish: 1 or 2 coats Ultra Spec® SCUFF-X™ Interior Satin Finish (486)

Rough or Pitted Masonry:

Primer: Ultra Spec® Masonry Interior/Exterior Hi-Build Block Filler (571)
Finish: 1 or 2 coats Ultra Spec® SCUFF-X™ Interior Satin Finish (486)

Smooth Poured or Precast Concrete:

Primer: Ultra Spec® Masonry Interior / Exterior 100% Acrylic Masonry Sealer (608)
Finish: 1 or 2 coats Ultra Spec® SCUFF-X™ Interior Satin Finish (486)

Ferrous Metal (Steel and Iron):

Primer: Ultra Spec HP® Acrylic Metal Primer (HP04) or Super Spec HP® Alkyd Metal Primer (P06)
Finish: 1 or 2 coats Ultra Spec® SCUFF-X™ Interior Satin Finish (486)

Wallpapered Surfaces: Remove wallpaper when possible, followed by thoroughly cleaning the surfaces removing all glue residue. Once the surface has fully dried, sand the surfaces to be painted with 150-180 grit paper. Vinyl wallpapered surfaces tightly adhered may be primed with Fresh Start® High-Hiding All Purpose Primer (046) prior to filling the seams and top coating with Ultra Spec® SCUFF-X™

Repair, All Substrates: Prime bare areas with the primer recommended for the substrate above.

Application

Stir thoroughly before use. Apply one or two coats. For best results, use a Benjamin Moore® Professional custom-blended nylon/polyester brush, Benjamin Moore® Professional roller, or a similar product. This product can also be sprayed.

Conditioning with Benjamin Moore® 518 Extender may be necessary under certain conditions to adjust open time or spray characteristics. The chart below is for general guidance		
	Mild conditions	Severe conditions
	Humid (RH> 50%) with no direct sunlight & with little to no wind	Dry (RH<50%), in direct sunlight, or windy conditions
Brush: Nylon / Polyester	No thinning necessary	Add 518 Extender or water: Max of 8 fl. oz. to a gallon of paint Never add other paints or solvents.
Roller: Premium Quality 3/8" roller cover		
Spray: Airless Pressure: 1800 -3000 psi Tip: 0.015-0.017		

Thinning/Clean Up

Thinning is unnecessary, but if required to obtain desired application properties, a small amount of clean water may be added. Never add other paints or solvents.

Clean up: Use soap and water. Spray equipment should be given a final rinse with mineral spirits to prevent corrosion.

USE COMPLETELY OR DISPOSE OF PROPERLY. Dry empty containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or state-designated environmental agency on disposal options.

Environmental Health & Safety Information

Use only with adequate ventilation. Do not breathe spray mist or sanding dust. Ensure fresh air entry during application and drying. Avoid contact with eyes and prolonged or repeated contact with skin. Avoid exposure to dust and spray mist by wearing a NIOSH approved respirator during application, sanding and clean up. Follow respirator manufacturer's directions for respirator use. Close container after each use. Wash thoroughly after handling.

WARNING: This product contains a chemical known to the state of California to cause cancer and birth defects, or other reproductive harm.

FIRST AID: In case of eye contact, flush immediately with plenty of water for at least 15 minutes; for skin, wash thoroughly with soap and water. If symptoms persist, seek medical attention. If you experience difficulty breathing, leave the area to obtain fresh air. If continued difficulty is experienced, get medical attention immediately.

IN CASE OF SPILL – Absorb with inert material and dispose of as specified under "Clean Up".

**KEEP OUT OF REACH OF CHILDREN
 PROTECT FROM FREEZING**

Refer to Safety Data Sheet for additional health and safety information.